

## Maintenance Guide Ultra High Purity Plus Reverse Osmosis

Countertop 4 Stage Water Filter System with Alkaliser

## PLEASE READ CAREFULLY BEFORE ATTEMPTING MAINTENANCE



## Step by Step Maintenance

Before attempting maintenance please ensure you have switched off the feed water to your system.

- 1. Remove the cover by compressing the clips at each end of the unit.
- 2. Taking note of the direction indicated on the filter label, unscrew the Carbon Pre-Filter and dispose.
- 3. Unscrew the Carbon Post-Filter and re-install it in the position of the Carbon Pre-Filter. *The Carbon Post-Filter* has only been used as a polishing filter, hence it can be re-used as the Carbon Pre-Filter.
- 4. Install the new Carbon Post-Filter by inserting the new filter into the existing head assembly.
- 5. To replace the Alkaliser Filter, remove the stem elbow (with blue tube inserted) from both the inlet and outlet of the filter cartridge - pushing on the filter's collet

whilst pulling the stem elbow. To install the new filter; if necessary remove any dust plugs and reattach the stem elbows with the blue tube inserted.

6. Flush the system before use; with the blue tube feeding to a drain, run water through the system for a few minutes. Dis-colouration and aeration may occur - this is normal and occurs when the non-toxic carbon fines and oxygen are flushed from the new cartridges.

Depending on water quality and usage, your RO Membrane should last 3-6 years. Your pure water quality can be tested with a conductivity meter measuring total dissolved solids (TDS) from the pure water outlet - this will indicate the rejection of contaminants ratio. A TDS Reader is available for purchase.

